



Installation and operating instructions

High-efficiency hot water storage tank

Installation and operating instructions
High-efficiency hot water storage tank

English

EKHWP300B
EKHWP300PB
EKHWP500B
EKHWP500PB

EKHWDH500B
EKHWDB500B

EKHWC500B
EKHWCH300B
EKHWCH500B
EKHWCB500B
EKHWCH300PB
EKHWCH500PB
EKHWCB500PB

1 General Information	4	7 Hydraulic connection	23
1.1 Refer to the manual	4	7.1 Connection diagrams	23
		7.1.1 Solution for low-temperature heat pumps	23
2 Safety	5	8 Service and maintenance	25
2.1 Warning signs and explanation of symbols	5	8.1 Periodic Checks	25
2.1.1 Meaning of the warnings	5	8.2 Annual inspection	25
2.1.2 Validity	5		
2.1.3 Handling instructions	5		
2.2 Avoiding danger	5	9 Technical data	26
2.3 Use as intended	6	9.1 Basic data	26
2.4 Instructions for operating safety	6	9.1.1 EKHWD	26
2.4.1 Before working on the hot water storage tank and the heating system	6	9.1.2 EKHWC	27
2.4.2 Electrical installation of optional accessories	6	9.1.3 EKHWP	29
2.4.3 Housing installation room	6	9.2 Performance diagrams	31
2.4.4 Requirements of the heating and filling water	6	9.2.1 EKHWD / EKHWC	31
2.4.5 Heating and sanitary side connection	7	9.2.2 EKHWP	31
2.4.6 Operation	7	9.3 Tightening torque	32
2.4.7 Instruct the owner	7		
2.4.8 Documentation	7	10 Notes	33
3 Product description	8	11 List of keywords	35
3.1 Design and components	8		
3.1.1 High-performance hot water storage tank for heat pump systems	9		
3.1.2 High-performance-hot water storage tank for all heat sources, excluding low-temperature heat pumps	11		
3.2 Brief description	13		
3.3 Scope of delivery	13		
3.4 Optional accessories	14		
3.4.1 Electric immersion heaters	14		
3.4.2 Non return valves	14		
3.4.3 Dirt filters	14		
3.4.4 Scalding protection	14		
3.4.5 Solar storage tank extension kit	14		
3.4.6 KFE filling connection	14		
4 Set-up and installation	15		
4.1 Installation	15		
4.1.1 Important information	15		
4.1.2 Installing the hot water storage tank	15		
4.2 Installation	16		
4.2.1 Important information	16		
4.2.2 Hydraulic system connection	17		
4.3 Filling / Topping Up	18		
4.3.1 Hot water-heat exchanger	18		
4.3.2 Buffer tank	18		
5 Start-up	20		
6 Taking out of operation	21		
6.1 Temporary shutdown	21		
6.2 Draining the storage tank	21		
6.2.1 With pre-mounted KFE filling connection	21		
6.2.2 With subsequently fitted KFE filling connection	21		
6.2.3 Without KFE filling connection	21		
6.2.4 Draining the heating circuit and hot water circuit	22		
6.2.5 Drain the solar panel circuit (only pressurised system)	22		
6.3 Final shutdown	22		

1 General Information

1 General Information

1.1 Refer to the manual

These instructions are a >> **translation of the original version** << in your language.

Please read this manual carefully and thoroughly before proceeding with the installation or modification of the heating system.

These instructions are intended for authorised and trained heating and sanitation experts who have experience in the proper installation and maintenance of heating systems and hot water storage tanks by virtue of their technical training and knowledge.

This manual provides all the necessary information for installation, start-up and maintenance, as well as basic information on operation and settings. Please see the attached documents for a detailed description of operation and control.

Relevant documents

- For connection to an external heat generator the associated installation and operating instructions.
- When connecting to a Daikin solar system the associated installation and operating instructions.

The guides are included in the scope of supply for the individual units.

2 Safety

2.1 Warning signs and explanation of symbols

2.1.1 Meaning of the warnings

Warnings in this manual are classified according to their severity and probability of occurrence.



DANGER!

Draws attention to imminent danger.

Disregarding this warning can lead to serious injury or death.



WARNING

Indicates a potentially dangerous situation.

Disregarding this warning may result in serious physical injury or death.



CAUTION!

Indicates a situation which may cause possible damage.

Disregarding this warning may cause damage to property and the environment.



This symbol identifies user tips and particularly useful information, but not warnings or hazards.

Special warning signs

Some types of danger are represented by special symbols:



Electric current



Risk of burning or scalding

2.1.2 Validity

Some information in this manual has limited validity. The validity is highlighted by a symbol.

 Pay attention to the stipulated tightening torque (see chapter 9.3 "Tightening torque").



Only applicable for the non-pressurised system (DrainBack).



Only applicable for the pressurised system

2.1.3 Handling instructions

- Handling instructions are shown as a list. Actions for which the sequential order must be maintained are numbered.
 - ➔ Results of actions are identified with an arrow.

2.2 Avoiding danger

The Daikin EKHWP / EKHCW / EKHCWD is state-of-the-art and is built to meet all recognised technical requirements. However, improper use may result in serious physical injuries or death, as well as property damage.

To prevent such risks, install and operate Daikin EKHWP / EKHCW / EKHCWD only:

- as stipulated and in perfect condition,
- with an awareness of safety and the hazards involved.

This assumes knowledge and use of the contents of this manual, of the relevant accident prevention regulations as well as the recognised safety-related and occupational health rules.



WARNING!

This unit is not intended for use by persons (including children) with impaired physical, sensory or mental faculties or persons with insufficient experience and/or expertise unless supervised by a person responsible for ensuring their safety or are given instruction by this person on how to use the unit.

- Keep flammable materials away from the Daikin EKHWP / EKHCW / EKHCWD.

2 Safety

2.3 Use as intended

The Daikin EKHWP / EKHCW / EKHWD may only be used as a hot water storage tank. The Daikin EKHWP / EKHCW / EKHWD must be installed, connected and operated only according to the information in this manual.

When connecting to a Daikin heat pump you must use only the storage tank connection kits (E-PAC) provided for the purpose.

Only those electric immersion heaters supplied by Daikin may be used.

Any other use outside the intended use is considered as improper. The operator alone shall bear responsibility for any resulting damage.

Intended use also includes compliance with the maintenance and service conditions. Replacement parts must at least satisfy the technical requirements defined by the manufacturer. This is the case, for example, with the use of original replacement parts.

2.4 Instructions for operating safety

2.4.1 Before working on the hot water storage tank and the heating system

- Work on the hot water storage tank and heating system (e.g. installation, connection and initial start-up) should only be carried out by authorised and trained heating experts.
- Switch off the main switch before starting any work on the domestic hot water storage tank and heating system and secure it against unintentional switch-on.
- Seals must not be damaged or removed.
- Make sure that the safety valves comply with the requirements of EN 12828 when connecting on the heating side, and with the requirements of EN 12897 when connecting on the domestic water side.
- Only original Daikin replacement parts may be used.

2.4.2 Electrical installation of optional accessories

- Before beginning work on live parts, disconnect them from the power supply (switch off main switch, remove fuse) and secure against unintentional restart.
- Electrical installations may only be carried out by qualified electrical technicians under observance of the relevant electrical guidelines and the regulations of the electric utilities company.
- For each hard wired power connection, install a separate disconnector system compliant with EN 60335-1 for all-pole disconnection from the power mains.
- Compare the mains voltage indicated on the nameplate with the supply voltage before connecting to the mains.

2.4.3 Housing installation room

For safe and fault-free operation, it is necessary that the installation location of the Daikin EKHWP / EKHCW / EKHWD fulfils certain criteria. Information on the installation location for the high-performance hot water storage tank can be found in chapter 4.2 "Installation".

Information on the installation site of other components can be found in the associated documentation supplied with them.

2.4.4 Requirements of the heating and filling water

Observe the current technological regulations to prevent corrosion products and deposits.

Minimum requirements regarding the quality of filling and supplementary water:

- Water hardness (calcium and magnesium, calculated as calcium carbonate):
≤ 3 mmol/l
- Conductivity: ≤ 1500 (ideal ≤ 100) µS/cm
- Chloride: ≤ 250 mg/l
- Sulphate: ≤ 250 mg/l
- pH value (heating water): 6.5 - 8.5

Use of filling water and top-up water which does not meet the stated quality requirements can cause a considerably reduced service life of the equipment. The responsibility for this lies solely with the operator.

2.4.5 Heating and sanitary side connection

- Create a heating system according to the safety requirements of EN 12828.
- With a sanitary connection you must comply with
 - EN 1717 – Protection against pollution of potable water installations and general requirements of devices to prevent pollution by backflow
 - EN 806 – Specifications for installations inside buildings conveying water for human consumption
 - and, in addition, the country-specific legal stipulations.



The domestic water quality must comply with the EU Guideline 98/83 EC and the regional applicable regulations.

The connection of a solar installation, an electric heating rod or an alternative heat generator may cause the storage temperature to exceed 60 °C.

- For this reason you should fit scalding protection (e.g. VTA32 + Screw connection set 1") during installation.
- Use a pressure reducer if the cold water connection pressure >6 bar.

If the Daikin EKHWP / EKHWC / EKHWD is connected to a heating system with steel pipes, radiators or non-diffusion-proof floor heating pipes, slurry and swarf could enter the hot water storage tank and cause blockages, local overheating or corrosion.

- To prevent possible damage, fit a dirt filter or sludge separator into the heating return flow of the system.
 - SAS 1

2.4.6 Operation

- Only operate the Daikin EKHWP / EKHWC / EKHWD:
 - After all installation and connection work has been completed.
 - With fully installed equipment covers and service accesses.
 - With sanitary side pressure reducers installed (max. 6 bar).
 - With heating side pressure reducers installed (max. 3 bar).
 - With completely filled storage containers (fill level display).

The prescribed maintenance intervals must be maintained and the inspection work must be carried out.

2.4.7 Instruct the owner

- Before you hand over the heating system and the hot water storage tank, explain to the owner how he/she can operate and check the heating system.
- Provide the operator with the technical documentation (this documentation and all its references) and indicate that these documents must be available in the immediate vicinity of the unit at all times.
- Document the hand-over by filling in and signing the checklist in chapter 5 "Start-up", together with the operator.

2.4.8 Documentation

The technical documentation contained in the scope of supply is part of the device. It must be stored in such a way that it can be consulted at any time by the operator or the technicians.

3 Product description

3 Product description

3.1 Design and components

Item	Explanation	Connection marking cover (Storage tank type)		Applicable to hot water storage tank
		(300 l)	(500 l)	
1	Storage tank (polypropylene double walled jacket with PUR hard foam heat insulation)			all
2	Mount for Solar R4 controller / handle			all
3	Name plate			all
4	Fill level indicator			all
5	Safety overflow connection (1½" AG, 1" IG)			all
6	Pressure-free storage water			all
7	Hot water zone			all
8	Solar zone			S#B / S#F / S#L / S#K
9	Connection for electric immersion heater / booster heater (R 1½" IG)			all
10	Optional: Electric immersion heater (designated as a booster heater in heat pump systems.)			all
11	Corrugated stainless steel pipe heat exchanger for domestic hot water using depressurised storage tank water			all
12	Stainless steel corrugated pipe heat exchanger for charging storage tank (SL-WT1) via 1st. heat source			S#B / S#D / S#F - S#M / S#O / S#P
13	Stainless steel corrugated pipe heat exchanger for charging storage tank (SL-WT2) via 2nd. heat source			S#I / S#L / S#P
14	Corrugated pipe stainless steel heat exchanger for heating support			S#B / S#F / S#H / S#I / S#L / S#K
15	Heat insulating jacket for heat exchanger to provide support for the heating			S#B / S#F / S#H / S#I / S#L / S#K
16	Stainless steel corrugated pipe heat exchanger for charging pressurised solar storage tank (SL-WT3)			S#F / S#G / S#K - S#M
17	Thermal insulation shell for pressurised solar heat exchanger (SL-WT3)			S#F / S#K / S#L
18	Solar inflow layering pipe			S#B / S#D / S#H / S#I / S#J / S#Q
19	Sensor pocket for tank temperature sensor	8	10	all
20	DrainBack solar - return flow			S#B / S#D / S#H - S#J / S#Q
	Filling and draining connection for storage tank water			all
21	DrainBack solar - inflow	7	9	S#B / S#D / S#H - S#J / S#Q
22	Pressurised solar - return flow	5	9	S#F / S#G / S#K - S#M
23	Pressurised solar - flow	6	11	S#F / S#G / S#K - S#M
24	Hot water connection *	2		all
25	Cold water connection *	1		all
26	Storage tank charging return flow (via 1st. heat source) *	3		S#B / S#D / S#F - S#M / S#O / S#P
27	Storage tank charging flow (via 1st. heat source) *	4		S#B / S#D / S#F - S#M / S#O / S#P
28	Storage tank charging return flow (via 2nd. heat source) *	-	5	S#I / S#L / S#P
29	Storage tank charging flow (via 2nd. heat source) *	-	6	S#I / S#L / S#P
30	<u>Excluding Altherma LT:</u> Heating support outlet ↓* (connect to heating return!) <u>Only Altherma LT:</u> Storage tank conditioning/heating support return flow ↑ (connect to heating inflow)	7		S#B / S#F / S#H / S#I / S#K / S#L
31	<u>Excluding Altherma LT:</u> Heating support inlet ↑* (connect to heat generator return flow!) <u>Only Altherma LT:</u> Storage tank conditioning/heating support inflow ↓ (connect to Altherma LT inflow)	8		S#B / S#F / S#H / S#I / S#K / S#L
S#B	Domestic hot water storage tanks EKHP500B			
S#D	Domestic hot water storage tanks EKHP300B			
S#F	Domestic hot water storage tanks EKHP500PB			
S#G	Domestic hot water storage tanks EKHP300PB			
S#Q	Domestic hot water storage tanks EKHW500B			
S#H	Domestic hot water storage tanks EKHWCH500B			
S#I	Domestic hot water storage tanks EKHWCB500B			
S#J	Domestic hot water storage tanks EKHWCH300B			
S#K	Domestic hot water storage tanks EKHWCH500PB			
S#L	Domestic hot water storage tanks EKHWCB500PB			
S#M	Domestic hot water storage tanks EKHWCH300PB			
S#O	Domestic hot water storage tanks EKWDH500B			
S#P	Domestic hot water storage tanks EKWDB500B			
X	Recommended wall distance 200 mm			all
AG	outer thread			all
IG	internal thread			all
*	Recommended accessory (ZKB (2x))			all

Tab. 3-1 Legend designation for figures in chap. 3.1.1 and 3.1.2.

3.1.1 High-performance hot water storage tank for heat pump systems

Non-pressurised system - DrainBack p=0




Fig. 3-1 Connections and dimensions, high-performance-hot water storage tank with solar support - p=0 type EKHWP 300/500B

3 Product description

Pressurised system 







Fig. 3-2 Connections and dimensions, high-performance-hot water storage tank with solar support -  type EKHWP 300/500BP

3.1.2 High-performance-hot water storage tank for all heat sources, excluding low-temperature heat pumps

Non-pressurised system - DrainBack $p=0$




Fig. 3-3 Connections and dimensions, high-performance-hot water storage tank with solar support - $p=0$ types EKHWC*B / EKHWD*B

3 Product description

Pressurised system 




Fig. 3-4 Connections and dimensions, high-performance-hot water storage tank with solar support -  type EKHWC*PB

3.2 Brief description

The Daikin high-performance-hot water storage tank is a combination of a heat storage tank and instantaneous water heater.

The pressureless storage water serves as heat storage medium. Useful heat is supplied and removed via the spiral corrosion-resistant heat exchanger, which is made from a corrugated stainless steel pipe (1.4404), and is completely immersed in the storage tank water. In the heat exchanger for domestic hot water generation, domestic hot water is stored at the temperature level of the preparation zone.

The cold water which flows out when the hot water is removed is first routed to the storage tank at the very bottom of the heat exchanger, where it cools the lower area of the storage tank down as much as possible. The readiness zone is heated by an external heat generator (condensing boiler, heat pump, solar system, electric immersion heater). Water flows through the heat exchanger for storage charging (SL-WT) from top to bottom.

On its way to the top, the domestic water continuously absorbs the heat of the storage tank water. The flow direction, operating on the principle of counter-flow, and the coil-shaped heat exchanger create a pronounced temperature layering in the hot water storage tank. As high temperatures can be maintained for a very long time in the upper section of the storage tank, a high hot water output is achieved even if water is drawn off over a long period of time.

The Daikin high-performance-hot water storage tanks EKHWP / EKHWC can also be solar heated, in addition to by an external heat generator. Depending on the available heat from the sun, the entire hot water storage tank can be heated up. The stored heat is now used both for hot water generation and for heating support. The high total storage capacity also temporarily allows time without sunshine to be bridged.

If a Daikin heat pump system is used as an external heat generator, the primary hot water storage tank can only be one of the "hot water storage tanks for heat pump systems" listed in chap. 3.1.1 or 3.1.2.

Optimum water hygiene

Low flow or unheated zones on the domestic water side are completely excluded with the Daikin high-performance-hot water storage tank. It is impossible for sludge, rust or other sediments to be deposited, as can be the case with other large volume tanks. The water which is fed into the system first is also discharged first (first in, first out principle).

Low maintenance and corrosion

The Daikin high-performance hot water storage tank is made of plastic and is completely corrosion free. No sacrificial anode or similar corrosion protection system is necessary. This means that associated maintenance work, e.g. changing the protective anodes or cleaning the storage tank, does not need to be carried out on the Daikin high-performance-hot water storage tank. Only the fill level of the storage tank water needs to be checked.

The corrugated stainless steel pipe heat exchangers on the heating and potable water side are made from high quality stainless steel (1.4404).

Low scaling

On the storage tank side only one deposition of scale is possible. The immersion heater therefore remains clean, as do all the stainless steel heat exchanger pipes in the storage tank water. This means that no scale can build up which would continuously reduce the efficiency of heat transfer in the course of operation (as is the case with other storage tank designs).

The thermal and pressure expansion and high flow rates in the domestic water heat exchanger release any possible scale deposits, which are then flushed away.

Economical operation

The full area heat insulation of the storage tank ensures very low heat losses in use and means that the best use is made of the heat energy being applied.

Modular extension facility


If the heat output of a single Daikin high-performance hot water storage tank is not adequate you can modularly interconnect several storage tanks.

Electronic control

A control system integrated in the heat generator controls all heating and hot water functions for the direct heating circuit, a mixed heating circuit which can be connected as an option and a storage tank charging circuit.

3.3 Scope of delivery

- Daikin EKHWP / EKHWC / EKHWD hot water storage tank
- Bag of accessories (see fig. 3-5)



- | | | | |
|---|---|---|---|
| A | Carrier loops (only required for transport) | C | Hose connection piece for safety overflow |
| B | Cover screen | D | Spanner |

Fig. 3-5 Content of bag of accessories

3 Product description

3.4 Optional accessories

3.4.1 Electric immersion heaters

In addition to the heating capability via the corrugated stainless steel pipe heat exchanger and various different heat sources and energy carriers, the Daikin high-performance hot water storage tank can also be charged using an electric immersion heater.

For EKHWC / EKHWD

Type	EHS/500/1	EHS/500/5	EHS/500/6
Operating voltage	230 V / 50 Hz	230/400 V / 50 Hz	230/400 V / 50 Hz
Heating output	2 kW	2, 4, 6 kW	2, 4, 6 kW
Temperature range ¹⁾	30-78 °C		
Safety temperature limit ¹⁾	95 °C	98 °C	
Cable length		—	—
Heating element length	1.42 m	1.42 m	1.10 m
Screw-in thread	R 1½"	R 1½"	R 1½"
Suitable for	All EKHWD + EKHWC ²⁾	All EKHWD + EKHWC ²⁾	Only for EKHWC

Tab. 3-2 Electric immersion heaters - overview and technical data

- 1) Temperature regulation and a safety temperature limiter (STB) are already integrated in the electric immersion heater. The electric immersion heater is delivered ready for fitting.
- 2) The longer heating element means that the solar zone on the EKHWC is also heated if electric charging is used. This can reduce the efficiency of the solar system.

For EKHWP (booster heater)

Type	BO3s F
Operating voltage	230 V / 50 Hz
Heating output	3 kW
Temperature range	35-65 °C
Cable length	—
Heating element length	0.9 m
Screw-in thread	R 1½"
Suitable for	All EKHWP

Tab. 3-3 Booster Heater - Overview and technical data

3.4.2 Non return valves

To prevent heat loss from the connection pipes when the circulation pump is switched off and during periods when no domestic water is drawn off (gravity circulation), you should fit circulation brakes in the connections for the Daikin high-performance hot water storage tank (see tab. 3-1).

3.4.3 Dirt filters

If the Daikin high-performance hot water storage tank is connected to a heating system with steel pipes, radiators or non-diffusion-proof floor heating pipes, slurry and swarf could enter the hot water storage tank and cause blockages, local overheating or corrosion. This can be prevented by fitting a dirt filter or sludge trap (see Daikin price list).

3.4.4 Scalding protection

There is a danger of scalding at hot water temperatures over 60 °C. Fitting scalding protection enables the hot water temperature to be varied continuously and limited from 35 - 60 °C.

- Scalding protection VTA32
- Screw connection set 1"

3.4.5 Solar storage tank extension kit

If the heat output of a single Daikin hot water storage tank is not adequate you can interconnect several EKHWP / EKHWC / EKHWD modules.

This means that both the stainless steel heat exchangers for post-heating and the hot water heat exchangers are interconnected in accordance with the Tichelmann principle (chapter 7 "Hydraulic connection").

With seasonal variations in demand these individual units can be added or taken out of service accordingly. In this way the total hot water output can be manually matched to the actual demand.

The following components are offered:

- Solar storage tank extension kit CON SX
- Solar storage tank extension kit 2 CON SXE
- FlowGuard FLG

The installation and operation of this accessory component is described in detail in the individual operating and installation instructions provided.

3.4.6 KFE filling connection

For convenient filling and draining of the Daikin hot water storage tank, you can connect the KFE filling connection (KFE BA).

4 Set-up and installation

4.1 Installation

4.1.1 Important information



WARNING!

The storage tank plastic wall on the Daikin EKHWP / EKHCW / EKHDW can melt under the effects of external heat ($>90^{\circ}\text{C}$) and, in the extreme case, can catch fire.

- Erect the Daikin EKHWP / EKHCW / EKHDW only at a minimum distance of 1 m to other heat sources ($>90^{\circ}\text{C}$) (e.g. electric heater, gas heater, chimney) and flammable materials.



CAUTION!

- Only erect the Daikin EKHWP / EKHCW / EKHDW if an adequate **ground load-bearing capacity of (1050 kg/m^2 plus a safety factor)** is guaranteed. The ground must be flat and level.
- Erection outdoors is only possible to a limited extent. The storage tank may **not be exposed to continuous direct sunlight**, as the UV radiation and the effects of the weather will damage the plastic.
- The Daikin EKHWP / EKHCW / EKHDW must be **protected from frost**.
- Make sure that the supply company **does not provide corrosive domestic water**.
 - Suitable water treatment may be required.



CAUTION

If the difference in height between the hot water storage tank and the solar panels is not great enough, the depressurised solar system cannot drain fully in the exterior section.

- On depressurised solar systems, observe the minimum gradient of the solar connection lines.



EKHWP


Observe the permitted lengths of pipes between the hot water storage tank and the hydraulic connections on the heat pump (see installation and operating instructions of the heat pump and the relevant storage tank connecting kit "E-PAC").

Requirement: The installation site meets the applicable country-specific requirements.

Incorrect set-up and installation would render the manufacturer's guarantee void. If you have questions, please contact our Technical Customer Service.

4.1.2 Installing the hot water storage tank

- Remove the packaging and dispose of it in an environmentally sound manner.
- Remove the cover plates on the storage tank (fig. 4-1, item B) and unscrew the threaded pieces (fig. 4-1, item F) from the apertures on which the handles are to be mounted.
- Pull the carrier loops (fig. 4-1, item A) through the threaded pieces.
- Screw the threaded pieces with the fitted carrier loops (fig. 4-1, item A+F) using a fitting spanner (fig. 4-1, item D) into the openings.



A Carrier loop
B Cover screen

D Spanner
F Threaded piece

Fig. 4-1 Mounting the handles

4 Set-up and installation

- Transport the hot water storage tank carefully to the site of erection, using the **carrier loops** provided.
- Install the domestic hot water storage tank at the installation site. **Recommended distance** to the wall (s1): ≥ 200 mm (fig. 4-2).



For installation of an optional **electrical immersion heater** (see chap. 3.4) you will need a **minimum distance "X"** of ≥ 1200 mm **to the ceiling**.



When setting up the unit in a cabinet, behind panels or in other restricted conditions, sufficient ventilation (e.g., using ventilation gratings) must be ensured.




Fig. 4-2 Install hot water storage tank (shown on the EKHWP)

4.2 Installation

4.2.1 Important information



WARNING!

There is a danger of scalding at water temperatures >60 °C. This can arise with solar energy utilisation, if the Legionella protection is activated or if the target temperature is set to >60 °C.

- Fit scalding protection (see chapter 3.4.4 "Scalding protection").



CAUTION!

If the hot water storage tank is connected to a heating system with **steel pipes**, **radiators** or non-diffusion-proof underfloor heating pipes, sludge and swarf could enter the hot water storage tank and cause **blockages**, local **overheating** or **corrosion**.

- Flush the feed pipes before filling the heat exchanger.
- Rinse out the heat distribution network (in the existing heating system).
- Fit a dirt filter or sludge catcher in the heating return pipe (see chap. 3.4.3).



CAUTION!

If the heat exchanger has an **external heating unit** (e.g. pressurised solar system, wood-burning boiler) connected for charging the **pressurised solar system** (fig. 3-4 / fig. 3-2, item 22+23), too high a flow temperature can cause damage to or destroy the Daikin EKHWP / EKHWC / EKHWD.

- The **feed flow temperature** of the external heater should be **limited to max. 95°C**.

- For **domestic water pipes** observe the stipulations of EN 806 and EN 1717.
- The position and dimensions of the connections can be taken from fig. 3-1 to fig. 3-4.
- Check the cold water connection pressure (maximum 6 bar).
 - If a higher pressure is present in the domestic water pipe, a pressure reducer will need to be installed.
- Connect the pressure relief line to the safety pressure relief valve (customer supply) and connect the diaphragm expansion tank as per EN 12828.

-  Note tightening torque (see chapter 9.3 "Tightening torque").
- Observe the requirements for the heating and filling water (see chap. 2.4.4).



To prevent heat loss from the connection pipes when the heating pump is switched off and during periods when no domestic water is drawn off (gravity circulation), you should fit **circulation brakes** (see chap. 3.4.2) in the connections for the Daikin hot water storage tank.

4.2.2 Hydraulic system connection

1. Only with connection of a EKHWP hot water storage tank to a Daikin heat pump:
 - Mount the storage tank kit "E-PAC" for the Daikin heat pump to the EKHWP hot water storage tank (see the individual installation and operating instructions included for the storage tank connection kit).
2. When using **circulation brakes**, fit them into the pipe connections on the Daikin EKHWP / EKHWC / EKHWD.
3. Connect the drain hose to the connector of the safety overflow (fig. 3-1 to fig. 3-4, item 15) on the hot water storage tank.
 - Use transparent drain hose (draining water must be visible).
 - Connect the drain hose to an adequately dimensioned waste water installation.
 - Drain should not be lockable.





Fig. 4-3 Installation of drain hose at safety overflow

4. Check the water pressure at the cold water connection (<6 bar).
 - ➔ If the pressure in the domestic water supply is greater then fit a pressure reducer and limit the water pressure to <6 bar.
5. Establish connection of the cold water inlet to the hot water storage tank (fig. 3-1 to fig. 3-4, item 25).



In order to be able to flush out the stainless steel corrugated heat exchanger for domestic hot water heating in the event of bad water quality, install a removal facility to each of the cold water and hot water connections on the storage tank (T-piece with draw-off cock).

Above a hardness level of >3 mmol/l we recommend also fitting a dirty water filter that can be back-flushed into the cold water connection.

6. Connect the connections to the hot water distribution network (fig. 3-1 to fig. 3-4, item 24).
7. Establish connections to the heating circuit.

You must always ensure proper de-aeration of the storage tank lines (fig. 3-1 to fig. 3-4, items 26-29)

 - **EKHWC / EKHWD**: Establish the drainage connection on site.
 - **EKHWP**: Use storage tank connection kit (E-PAC, see price list).
8. Establish connections to the heat generator.
 - **EKHWC / EKHWD**: Establish the connections to the heat generator in accordance with the suitable system diagram (chapter 7.1 "Connection diagrams").
 - **EKHWP**: In combination with a Daikin heat pump, the heating side connection of the hot water storage tank must be carried out in accordance with the installation and operating instructions of the respective storage tank connection kit (E-PAC).
 - **With bivalent combustion**, the connections need to be carried out in accordance with the connection schematic in the installation and operating instructions of the individual controllers.
 - **Optional**: Create the connections to the **solar system** (see solar installation and maintenance instructions).
9. Carefully lag the hot water pipes to prevent heat loss. Install heat installation in accordance with country-specific guidelines. Daikin recommends a lag thickness of at least 20 mm.

4 Set-up and installation

4.3 Filling / Topping Up



Any optional accessories must be fitted before filling.



The heat exchangers must be filled before the buffer storage tank.

4.3.1 Hot water-heat exchanger

1. Open the shutoff valve for the cold water supply pipe.
2. Open the hot water tap connections so that the draw-off volume can be set as high as possible.
3. Once water has been discharged from the tap connections, do not interrupt the cold water flow; this will ensure that the heat exchanger will be fully vented and that any impurities or residue will be discharged.

4.3.2 Buffer tank



WARNING!

Live parts can cause an electric shock on contact and cause fatal burns or injuries.

- If there is an electric immersion heater / Booster Heater or regulation and pump station installed in the hot water storage tank then these components must be isolated from the power supply before starting the work (e.g. fuse, main switch switched off and secured against inadvertent switching on again).



UK only!

CAUTION!

If filling or topping up the storage tank is done by means of the boiler filling and drain valve, a temporary filling loop must be used with the appropriate backflow prevention device in accordance with clause G24.2, Guidance to the Water Supply (Water Fittings) Regulations 1999.



Fill the solar circuit, heating system and storage tank charging circuit in accordance with the operating instructions for the individual components.

EKHWP / EKHWC hot water storage tank without solar system and without KFE filling connection p=0 (KFE BA)

- Connect the filling hose with non-return valve (1/2") to the "DrainBack - feed" connection (fig. 4-4, item 21).
- Fill the storage tank on the Daikin EKHWP / EKHWC **until water comes out of the safety overflow** (fig. 4-4, item 5).
- Disconnect the filling hose with backflush prevention (1/2") again.




Fig. 4-4 Filling the buffer storage tank - without p=0 solar system and without KFE filling connection

All EKHWD hot water storage tanks:

- Install a KFE filling connection (accessory KFE BA) to the filling and draining connection on the Daikin EKHWD.
- Connect the **filling hose** with backflush prevention (1/2") to the previously installed **KFE filling connection**.
- Fill the storage tank on the Daikin EKHWD **until water comes out of the safety overflow** (fig. 4-4, item 5).

EKHWP / EKHWC hot water storage tank with solar system

- Installing a KFE filling connection (accessory KFE BA):
 - With $p=0$ solar system:** on the connection bracket of the regulation and pump unit (EKS RPS3).
 - With $p \neq 0$ solar system:** on the filling and draining connection of the Daikin EKHWP / EKHWC.
- Connect the **filling hose** with backflush prevention (1/2") to the previously installed **KFE filling connection**.
- Only with $p=0$ solar system:
Adjust the valve insert on the connecting angle so that the path to the filling hose is opened (fig. 4-5).
- Open the KFE cock on the **KFE filling connection** and the cold water inlet and fill the storage tank for the Daikin EKHWP/EKHWC **until water comes out of the safety overflow** (fig. 4-5, item 5).




Fig. 4-5 Filling the buffer storage tank - with KFE filling connection

5 Start-up

5 Start-up



WARNING!

- Units which have been set-up and installed incorrectly may not operate properly and can be a health and safety risk endangering human life.
- Installation commissioning may only be carried out by authorized and trained heating technicians following the installation and maintenance manual included.
- Only original Daikin replacement parts may be used.



CAUTION!

If the booster heater is started with the storage tank empty or not completely full, it can lead to a reduction in performance of the electric heating (tripping of the safety temperature limiter).

- Operate the electric immersion heater / booster heater only with the storage tank completely full.

Incorrect start-up makes the manufacturer's guarantee for the unit void. If you have questions, please contact our Technical Customer Service.



CAUTION!

A hot water storage tank commissioned improperly can lead to property damage.

- Observe the regulations in VDI 2035 in order to avoid corrosion and deposits.
- For **filling and top-up water with high water hardness**, take measures for softening the water or **stabilising hardness**.
- Set the **pressure reducer** on the cold water connection to a **maximum of 6 bar**.

- Check all the points on the enclosed checklist. Make a record of the test results and sign it, together with the operator.
- If an electric immersion heater / booster heater is fitted, set the desired storage tank water temperature.
- Switch on the mains supply switch on the heat generator. Wait for the start phase.

Only if **all points** on the checklist can be answered with **Yes** may the Daikin EKHWP / EKHWC / EKHWB be started up.

Check list for start-up

1.	Is the hot water storage tank is correctly set up according to an admissible set up variant and without visible damages?	☐ Yes
2.	Minimum distance between the hot water storage tank and other heat sources (>90 °C) of 1 m?	☐ Yes
3.	Hot water storage tank fully connected, including optional accessories?	☐ Yes
4.	With a fitted electric immersion heater / booster heater: – Does the mains connection comply with the regulations and is the mains voltage 230 volts or 400 volts, 50 Hz? – Has the residual current device been fitted in accordance with the individual country-specific regulations? – Only when using non-flammable power supply cable: Has the electric cable not been laid directly to the hot water storage tank?	☐ Yes ☐ Yes ☐ Yes
5.	Is the storage tank is filled with water to the overflow point?	☐ Yes
6.	On restoration: Has the heat distribution network been cleaned? Is a dirt filter installed in the heating return flow?	☐ Yes
7.	Is the safety overflow connection connected to an open drain?	☐ Yes
8.	Heating system and hot water system full?	☐ Yes
9.	Is the water pressure on the sanitary side < 6 bar?	☐ Yes
10.	Is the water pressure on the heating side < 3 bar?	☐ Yes
11.	Are the heat generator and heating system vented?	☐ Yes
12.	Are all hydraulic connections tight (leaks)?	☐ Yes
13.	Does the installation operate without faults?	☐ Yes
14.	In the case of new installations: Has the operating manual been handed over, and has the owner been instructed?	☐ Yes

Location and

Date:

Signature of installer:

Signature of owner:

6 Taking out of operation



If installed: Switch off the power supply to the Daikin electric immersion heater / booster heater.

6.1 Temporary shutdown



CAUTION!

A heating system which is shut down can freeze in the event of frost and may suffer damage.

- In the event of a danger of frost, start the entire Daikin heating system up again and activate the frost protection function or take the appropriate frost protection measures for the hot water storage tank (e.g. by draining).



If there is a risk of frost for a few days only, the excellent heat insulation of the Daikin EKHWP / EKHWC / EKHWB hot water tank means that it need not be drained as long as the storage tank temperature is observed regularly and does not fall below +3 °C. This does not, however, provide any protection against frost for the connected heat distribution system.

If a storage tank temperature of less than +3 °C is reached, the STB of the electric immersion heater / booster heater automatically triggers. This prevents consequential damage to the electric immersion heater caused by frost when starting up again.

6.2 Draining the storage tank



WARNING!

Danger of scalding caused by emerging hot water from the storage tank.

- Allow the hot water storage tank to cool down adequately before any installation work.
- Wear protective gloves.

6.2.1 With pre-mounted KFE filling connection

- Connect the drain hose to the **KFE filling connection** (fig. 6-1 / fig. 6-2) and to a waste water drainage point which is at least at ground level.
- Only with $p=0$ solar system:
Adjust the valve insert on the connecting angle so that the path to the drain hose is opened (fig. 6-2).
- Open the **KFE filling connection** and drain the water out of the storage tank (fig. 6-1 / fig. 6-2).




Fig. 6-1 Draining process **without** $p=0$ solar system




Fig. 6-2 Draining process **with** $p=0$ solar system

6.2.2 With subsequently fitted KFE filling connection

- Install the **KFE filling connection** (accessory KFE BA) subsequently.
- Drain the storage tank content as described in chap. 6.2.1.

6.2.3 Without KFE filling connection

With $p=0$ solar system



Draining is only possible with the **KFE filling connection** (accessory KFE BA) (see chap. 6.2.1).

Without $p=0$ solar system



Draining with the **KFE filling connection** (accessory KFE BA) is recommended.

Alternative:

1. Remove the hose connection piece (fig. 6-3, item C) from the safety overflow (fig. 6-3, item B).





Fig. 6-3 Step 1



Optional: Removing the connection piece from the safety overflow

2. Remove the cover plate from the filling and emptying fitting.
3. Remove the cover plate from the handle and unscrew the threaded piece (fig. 6-4, item E) from the storage tank container.




Fig. 6-4 Working steps 2 + 3

6 Taking out of operation

- Place a suitable collection trough beneath the filling and emptying fitting.



CAUTION!

Storage water will gush out as soon as the sealing plug is removed.

There is no valve and no non-return flap on the filling and draining connection.

- Unscrew the threaded piece (fig. 6-5, item E) at the filling and draining connection, remove the plug (fig. 6-5, item F) and immediately screw in the pre-assembled hose connector (fig. 6-5, item C) back into the filling and draining connection.




Fig. 6-5 Working steps 4 + 5

6.2.4 Draining the heating circuit and hot water circuit

- Connect the drain hose to the Daikin heat generator.
- Allow the heating and hot water circuits to drain using the suction lifter method.
- Disconnect the heating flow and return and the cold water feed and hot water discharge from the Daikin EKHWP / EKHWC / EKHWD.
- Connect the discharge hose on the heating flow and return flow as well as the cold water inflow and hot water outflow so that the hose opening is at ground level.
- Allow the individual heat exchangers to run empty one after the other based on the suction lifter method.

6.2.5 Drain the solar panel circuit (only pressurised system)



CAUTION!

If heat transfer media containing glycol are exposed to temperatures above 170 °C over an extended period, they will decompose or form silt. This may reduce the frost protection, affect the output of the solar system and damage components of the system.

- In the event of extended standstill of the solar panel circuit drain in accordance with the installation instructions of the regulating and pump unit.

6.3 Final shutdown

- Disconnect the Daikin EKHWP / EKHWC / EKHWD from all electrical and water connections.
- Dismantle the Daikin EKHWP / EKHWC / EKHWD in accordance with the instruction manual (chapter 4 "Set-up and installation") in reverse order.
- Dispose of the Daikin EKHWP / EKHWC / EKHWD in accordance with regulations.

Recommendations for disposal



Daikin, thanks to the environmentally friendly design of the EKHWP / EKHWC / EKHWD hot water storage tank, has established the preconditions to ensure environmentally friendly disposal. Proper disposal in compliance with the respective national regulations of the country of use is the responsibility of the user/owner.



The designation of the product means that electrical and electronic products may not be disposed of together with unsorted domestic waste.



Proper disposal in compliance with the respective national regulations of the country of use is the responsibility of the user/owner.

- Only a qualified technician may disassemble the system.
- Disposal may only be carried out by a facility that specialises in reuse, recycling and recovery.

Further information is available from the installation company or the responsible local authorities.

7 Hydraulic connection

Short name	Meaning
1	Cold water distribution network
2	Hot water distribution network
3	Heating flow
4	Heating return flow
5	Mixer circuit (optional)
6	Circulation (optional)
7	Check valve, return valve
7a	Non return valves
8	Solar circuit
9	Gas pipe (refrigerant)
10	Fluid pipe (refrigerant)
3UV1	3-way switch valve (DHW)
3UV2	3-way switch valve (cooling)
EKBOyy	Booster heater / electric immersion heater
BSK	Burner blockage contact in EKSRRPS4
BV	Bypass valve
C	Refrigerant compressor
CW	Cold water
DHW	Domestic hot water
E	Expansion valve
EP3	Hot water module E-PAC LT (heating/cooling)
FLG	FlowGuard - Solar regulating valve
FLS	FlowSensor - solar flow and flow temperature measurement
H ₁ , H ₂ ... H _m	Heating circuits
HYW	Low loss header
MAG	Diaphragm expansion vessel
MIX	3-way-mixer with drive motor
MK1	Mixer group with high-efficiency pump
MK2	Mixer group with high-efficiency pump (PWM controlled)
P ₁	Central heating pump
P _{HP}	Heating circulation pump
P _{Mi}	Mixing circuit pump
P _S	Solar operating pump  + 
P _Z	Circulation pump
PWT	Panel heat exchanger (condenser)
RLB	Return temperature limiter
EHS157068	Mixer circuit regulation
EKSRRPS4	Solar regulating and pump unit 
ERLQ	Heat pump external unit LT
EKHBX	Heat pump internal unit LT
RT	Room thermostat
S#B	Domestic hot water storage tanks EKHWP500B
SOL-M1	Solar communication module SOL-PAC2 LT
SK	Solar panel field
SV	Safety overpressure valve
t _{AU}	External temperature sensor
t _{DHW}	Storage tank temperature sensor (heat generator)
t _{Mi}	Inflow temperature sensor, mixer circuit

Short name	Meaning
t _K	Solar collector temperature sensor
t _R	Solar return flow temperature sensor
T _S	Solar storage cylinder temp. sensor
T _V	Solar flow temperature sensor
V	Fan (vaporiser)
VS	Scalding protection VTA32

Tab. 7-1 Abbreviations on hydraulics plans

8 Service and maintenance

The Daikin EKHWP / EKHWC / EKHWD is practically maintenance free as a result of its design. No corrosion protection equipment is required (such as sacrificial anodes). This means there is no need for maintenance work such as changing the protective anodes or cleaning the inside of the storage tank.

Regular inspection of the hot water storage tank guarantees a long working life and fault-free operation.



WARNING!

Live parts can cause an electric shock on contact and cause fatal burns or injuries.

- If there is an electric immersion heater / booster heater or regulation and pump station installed in the hot water storage tank then these components must be isolated from the power supply before starting the inspection and maintenance work (e.g. fuse, main switch switched off and secured against inadvertent switching on again).



WARNING!

All work performed on live components must be carried out in accordance with the proper procedures, otherwise there may be a danger to the life and health of individuals and the function may be impaired.

- Rectification of damage to live components may only be carried out by heating engineers authorised and recognised by the energy supply company.

- If a solar system is connected and is in operation, switch it off and empty the solar panels.
- Visual inspection of the general condition of the hot water storage tank.
- Visual check of the water storage tank level (filling level indicator)
 - ➔ Top up water if required (see chapter 4 "Set-up and installation", chap. 4.3.2) and also determine and remedy the cause for the low water level.
- Check the connection of the safety overflow and drain hose for leaks, free drainage and gradient.
 - ➔ If necessary, clean the safety overflow and drain hose and relay it; replace damaged parts.
- Visual inspection of connections and pipes. In the event of damage, determine the cause.
 - ➔ Replace defective parts.
- Check all electrical components, connections and cables.
 - ➔ Repair damaged parts or replace them.
- Check the water pressure of the cold water supply (<6 bar)
 - ➔ If necessary, fit or adjust pressure reducer.
- Clean the plastic storage tank **with soft cloths and a mild cleaning agent**. Do not use cleaning agents containing aggressive solvents, as this will damage the plastic surface.

8.1 Periodic Checks

The filling water can evaporate slightly over a period of time as a result of the design. This process does not represent a technical fault, but is rather a physical property which requires periodic checking and correction of the water level, if necessary, by the operator.

- Visual check of the water storage tank level (filling level indicator)
 - ➔ Top up water if required (see chapter 4 "Set-up and installation", chap. 4.3.2) and also determine and remedy the cause for the low water level.

8.2 Annual inspection

- Carry out a functional inspection of the electric immersion heater or booster heater by checking the temperature display and the switching states in the individual modes:
 - Electric immersion heater: see the associated installation and operating instructions.
 - Booster Heater: see chapter "Operation" in the associated installation and operating instructions.

9 Technical data

9 Technical data



Not all the hot water storage tanks listed here are offered certain countries.

9.1 Basic data

9.1.1 EKHWD

	Unit	EKHWDH500B	EKHWD500B
Energy Labelling Regulation: (EU) 812/2013 / Ecodesign Regulation: (EU) 814/2013			
Energy efficiency class	—	B	
Standing loss	W	72	
Hot water storage tank volume	litres	477	
basic data			
Empty weight	kg	73	76
Total filled weight	kg	585	591
Dimensions (L x W x H)	cm	79 x 79 x 165.8	
Tilt dimension	cm	167	
Maximum permissible storage water temperature	°C	85	
Heat consumption at stand-by and at 60 °C	kWh/24 h	1.4	
Drinking water heat exchanger (stainless steel 1.4404)			
Water capacity heat exchanger	litres	24.5	
Maximum operating pressure	bar	6	
Domestic water heat exchanger surface	m ²	5	
1. Storage tank charging heat exchanger (stainless steel 1.4404)			
Water capacity heat exchanger	litres	11.0	
Heat exchanger surface area	m ²	2.2	
2. Storage tank charging heat exchanger (stainless steel 1.4404)			
Water capacity heat exchanger	litres	—	10.9
Heat exchanger surface area	m ²	—	2.2
Heat technics power data			
Output characteristic N _L in accordance with DIN 4708 ¹⁾		4.1	4.4 / 4.8 ²⁾
Continuous output Q _D according to DIN 4708	kW	35	50 / 50 ²⁾
Maximum draw-off rate for the duration of 10 min on recharging at 35 kW (T _{KW} = 10 °C / T _{WW} = 40 °C / T _{SP} =60 °C)	l/min	30	31 / 34 ²⁾
Hot water quantity without reheating with up to 15 l/min draw-off rate (T _{KW} = 10 °C/T _{WW} = 40 °C/T _{SP} = 60 °C)	litres	420	
Hot water volume with post-heating at 15 l/min draw-off rate (post-charge output 20 kW) (T _{KW} =10 °C / T _{WW} =40 °C / T _{SP} =60 °C)	litres	970	
Short-term water quantity in 10 min	litres	310	
Pipe connections			
Cold and hot water	inches	1" AG	
Heating feed and return flow	inches	1" IG / 1" AG	

Tab. 9-1 Basic data EKHWD

1) With post-charging at 35 kW, 80 °C flow temperature, 65 °C storage tank temperature, 45 °C hot water temperature; 10 °C cold water temperature.

2) With parallel connection of both storage tank charging heat exchangers.

3) Data applies to draw-off rate of 20 l/min.

9.1.2 EKHWC

Non-pressurised (DrainBack) - DB p=0	Unit	EKHWCH300B	EKHW500B	EKHWCH500B	EKHWCB500B
Energy Labelling Regulation: (EU) 812/2013 / Ecodesign Regulation: (EU) 814/2013					
Energy efficiency class	—	B			
Standing loss	W	64	72		
Hot water storage tank volume	litres	294	477		
basic data					
Empty weight	kg	51	69	74	79
Total filled weight	kg	355	582	588	594
Dimensions (L x W x H)	cm	59.5 x 61.5 x 164.6	79 x 79 x 165.8		
Tilt dimension	cm	170	167		
Maximum permissible storage water temperature	°C	85			
Heat consumption at stand-by and at 60 °C	kWh/24 h	1.3	1.4		
Drinking water heat exchanger (stainless steel 1.4404)					
Water capacity heat exchanger	litres	19.0	24.5		
Maximum operating pressure	bar	6			
Domestic water heat exchanger surface	m ²	3.9	5.0		
1. Storage tank charging heat exchanger (stainless steel 1.4404)					
Water capacity heat exchanger	litres	9.4	—	10.5	
Heat exchanger surface area	m ²	1.9	—	2.1	
2. Storage tank charging heat exchanger (stainless steel 1.4404)					
Water capacity heat exchanger	litres	—	—	—	11.3
Heat exchanger surface area	m ²	—	—	—	2.3
Pressurised solar heat exchanger (stainless steel 1.4404)					
Water capacity heat exchanger	litres	—	—	—	—
Heat exchanger surface area	m ²	—	—	—	—
Solar heating backup (stainless steel 1.4404)					
Water capacity heat exchanger	litres	—	3.2		
Heat exchanger surface area	m ²	—	0.4		
Heat technics power data					
Output characteristic N _L in accordance with DIN 4708 ¹⁾		2.2	—	2.3	2.5
Continuous output Q _D according to DIN 4708	kW	27	—	35	45
Maximum draw-off rate for the duration of 10 min on recharging at 35 kW (T _{KW} = 10°C / T _{WW} = 40°C / T _{SP} =60°C)	l/min	21	—	22	24
Hot water quantity without reheating with up to 15 l/min draw-off rate (T _{KW} = 10 °C/T _{WW} = 40 °C/T _{SP} = 60 °C)	litres	200	230		230 / 405 ²⁾
Hot water volume with post-heating at 15 l/min draw-off rate (post-charge output 20 kW) (T _{KW} =10°C / T _{WW} =40°C / T _{SP} =60°C)	litres	400	—	500	500 / 858 ²⁾
Short-term water quantity in 10 min	litres	210	—	220	240
Pipe connections					
Cold and hot water	inches	1" AG			
Heating feed and return flow	inches	1" AG			
Solar connections	inches	1" AG	1" IG		1" AG

Tab. 9-2 Basic data EKHWC - DrainBack $p=0$

1) With post-charging at 35 kW, 80°C flow temperature, 65°C storage tank temperature, 45°C hot water temperature; 10°C cold water temperature.

2) With parallel connection of both storage tank charging heat exchangers.

9 Technical data

Pressurised system - P 	Unit	EKHWC300PB	EKHWC500PB	EKHWC500PB
Energy Labelling Regulation: (EU) 812/2013 / Ecodesign Regulation: (EU) 814/2013				
Energy efficiency class	—	B		
Standing loss	W	64	72	
Hot water storage tank volume	litres	294	477	
basic data				
Empty weight	kg	53	80	86
Total filled weight	kg	357	593	599
Dimensions (L x W x H)	cm	59.5 x 61.5 x 164.6	79 x 79 x 165.8	
Tilt dimension	cm	163	167	
Maximum permissible storage water temperature	°C	85		
Heat consumption at stand-by and at 60 °C	kWh/24 h	1.3	1.4	
Drinking water heat exchanger (stainless steel 1.4404)				
Water capacity heat exchanger	litres	19.0	24.5	
Maximum operating pressure	bar	6		
Domestic water heat exchanger surface	m ²	3.9	5.0	
1. Storage tank charging heat exchanger (stainless steel 1.4404)				
Water capacity heat exchanger	litres	9.4	10.5	
Heat exchanger surface area	m ²	1.9	2.1	
2. Storage tank charging heat exchanger (stainless steel 1.4404)				
Water capacity heat exchanger	litres	—	—	11.3
Heat exchanger surface area	m ²	—	—	2.3
Pressurised solar heat exchanger (stainless steel 1.4404)				
Water capacity heat exchanger	litres	4.2	12.5	
Heat exchanger surface area	m ²	0.8	1.7	
Solar heating backup (stainless steel 1.4404)				
Water capacity heat exchanger	litres	—	3.2	
Heat exchanger surface area	m ²	—	0.4	
Heat technics power data				
Output characteristic N _L in accordance with DIN 4708 ¹⁾		2.2	2.3	2.5
Continuous output Q _D according to DIN 4708	kW	27	35	45
Maximum draw-off rate for the duration of 10 min on recharging at 35 kW (T _{KW} = 10°C / T _{WW} = 40°C / T _{SP} =60°C)	l/min	21	22	24
Hot water quantity without reheating with up to 15 l/min draw-off rate (T _{KW} = 10 °C/T _{WW} = 40 °C/T _{SP} = 60 °C)	litres	200	230	230 / 405 ²⁾
Hot water volume with post-heating at 15 l/min draw-off rate (post-charge output 20 kW) (T _{KW} =10°C / T _{WW} =40°C / T _{SP} =60°C)	litres	400	500	500 / 858 ²⁾
Short-term water quantity in 10 min	litres	210	220	240
Pipe connections				
Cold and hot water	inches	1" AG		
Heating feed and return flow	inches	1" AG		
Solar connections	inches	3/4" IG / 1" AG		

Tab. 9-3 Basic data EKHWC - pressurised system 

1) With post-charging at 35 kW, 80 °C flow temperature, 65 °C storage tank temperature, 45 °C hot water temperature; 10 °C cold water temperature.

9.1.3 EKHWP

Non-pressurised (DrainBack) - DB p=0	Unit	EKHWP300B	EKHWP500B
Energy Labelling Regulation: (EU) 812/2013 / Ecodesign Regulation: (EU) 814/2013			
Energy efficiency class	—	B	
Standing loss	W	64	72
Hot water storage tank volume	litres	294	477
basic data			
Empty weight	kg	58	82
Total filled weight	kg	359	593
Dimensions (L x W x H) without switching unit from E-PAC	cm	59.5 x 61.5 x 164.6	79 x 79 x 165.8
Tilt dimension	cm	163	167
Maximum permissible storage water temperature	°C	85	
Heat consumption at stand-by and at 60 °C	kWh/24h	1.3	1.4
Drinking water heat exchanger (stainless steel 1.4404)			
potable water capacity	litres	27.9	
Maximum operating pressure	bar	6	
Domestic water heat exchanger surface	m ²	5.8	6.0
Storage tank charging heat exchanger (stainless steel 1.4404)			
Water capacity heat exchanger	litres	13.2	18.5
Heat exchanger surface area	m ²	2.7	3.8
Solar heating backup (stainless steel 1.4404)			
Water capacity heat exchanger	litres	—	2.3
Heat exchanger surface area	m ²	—	0.5
Heat technics power data			
Volume of hot water without reheating at draw-off rate (8 l ³) / 12 l/min ⁴) (T _{KW} = 10 °C / T _{WW} = 40 °C / T _{SP} = 50 °C)	litres	184 ³) / 153 ⁴)	364 ³⁾⁷) / 318 ⁴⁾⁷) 328 ³⁾⁸) / 276 ⁴⁾⁸)
Volume of hot water without reheating at draw-off rate (8 l ⁴) / 12 l/min ⁴) (T _{KW} = 10 °C / T _{WW} = 40 °C / T _{SP} = 60 °C)	litres	282 ³) / 252 ⁴)	540 ³) / 494 ⁴)
Volume of hot water without reheating at draw-off rate (8 l ⁴) / 12 l/min ⁴) (T _{KW} = 10 °C / T _{WW} = 40 °C / T _{SP} = 65 °C)	litres	352 ³) / 321 ⁴)	612 ³) / 564 ⁴)
Reheating time (Wh) with a draw-off quantity (bathtub: 140 l ⁵) / shower: 90 l ⁶) (T _{KW} =10 °C / T _{WW} =40 °C / T _{SP} =50 °C)	min	45 ⁵⁾⁹) / 30 ⁶⁾⁹)	25 ⁵⁾¹⁰) / 17 ⁶⁾¹⁰)
Pipe connections			
Cold and hot water	inches	1" AG	
Heating flow / return flow	inches	1" IG / 1" AG	
Solar connections	inches	1" IG	

Tab. 9-4 Basic data EKHWP - DrainBack p=0

7) Charging by heat pump and electric booster heater.

8) Charging only by heat pump without electric booster heater.

9) With heat pump 8 kW.

10) With heat pump 16 kW.

9 Technical data

Pressurised system - P 	Unit	EKHWP300PB	EKHWP500PB
Energy Labelling Regulation: (EU) 812/2013 / Ecodesign Regulation: (EU) 814/2013			
Energy efficiency class	—	B	
Standing loss	W	64	72
Hot water storage tank volume	litres	294	477
basic data			
Empty weight	kg	58	89
Total filled weight	kg	364	598
Dimensions (L x W x H) without switching unit from E-PAC	cm	59.5 x 61.5 x 164.6	79 x 79 x 165.8
Tilt dimension	cm	170	167
Maximum permissible storage water temperature	°C	85	
Heat consumption at stand-by and at 60 °C	kWh/24 h	1.3	1.4
Domestic hot water (stainless steel 1.4404)			
potable water capacity	litres	27.9	29.0
Maximum operating pressure	bar	6	
Domestic water heat exchanger surface	m ²	5.8	
Storage tank charging heat exchanger (stainless steel 1.4404)			
Water capacity heat exchanger	litres	13.2	18.5
Heat exchanger surface area	m ²	2.7	3.8
Pressurised solar heat exchanger (stainless steel 1.4404)			
Water capacity heat exchanger	litres	4.2	12.5
Heat exchanger surface area	m ²	0.8	1.7
Solar heating backup (stainless steel 1.4404)			
Water capacity heat exchanger	litres	—	2.3
Heat exchanger surface area	m ²	—	0.5
Heat technics power data			
Volume of hot water without reheating at draw-off rate (8 l ³⁾ / 12 l/min ⁴⁾) (T _{KW} = 10 °C / T _{WW} = 40 °C / T _{SP} = 50 °C)	litres	184 ³⁾ / 153 ⁴⁾	324 ³⁾⁷⁾ / 282 ⁴⁾⁷⁾ 288 ³⁾⁸⁾ / 240 ⁴⁾⁸⁾
Volume of hot water without reheating at draw-off rate (8 l ⁴⁾ / 12 l/min ⁴⁾) (T _{KW} = 10 °C / T _{WW} = 40 °C / T _{SP} = 60 °C)	litres	282 ³⁾ / 252 ⁴⁾	492 ³⁾ / 444 ⁴⁾
Volume of hot water without reheating at draw-off rate (8 l ⁴⁾ / 12 l/min ⁴⁾) (T _{KW} = 10 °C / T _{WW} = 40 °C / T _{SP} = 65 °C)	litres	352 ³⁾ / 321 ⁴⁾	560 ³⁾ / 516 ⁴⁾
Reheating time (Wh) with a draw-off quantity (bathtub: 140 l ⁵⁾ / shower: 90 l ⁶⁾) (T _{KW} =10 °C / T _{WW} =40 °C / T _{SP} =50 °C)	min	45 ⁵⁾⁹⁾ / 30 ⁶⁾⁹⁾	25 ⁵⁾¹⁰⁾ / 17 ⁶⁾¹⁰⁾
Pipe connections			
Cold and hot water	inches	1" AG	
Heating flow / return flow	inches	1" IG / 1" AG	
Solar connections	inches	3/4" IG / 1" AG	

Tab. 9-5 Basic data EKHWP - pressurised system 

7) Charging by heat pump and electric booster heater.


8) Charging only by heat pump without electric booster heater.

9) With heat pump 8 kW.

10) With heat pump 16 kW.

9.2 Performance diagrams

9.2.1 EKHWD / EKHWC



S#Q EKHWC500B
S#H EKHWC500B
S#I EKHWC500B
S#J EKHWC300B
S#K EKHWC500PB
S#L EKHWC500PB
S#M EKHWC300PB

S#O EKHWDH500B
S#P EKHWD500B


Z / L/min
Draw-off rate in litres per minute
 $V_{z,max}$ / L
Maximum draw-off rate in litres

Hot water volume with reheating at a rating of 20 kW
($T_{KW} = 10^\circ\text{C}$, $T_{WW} = 40^\circ\text{C}$, $T_{SP} = 60^\circ\text{C}$)

Fig. 9-1 Hot water output with respect to draw-off rate



Draw-off rates >36 l/min can, in certain rare circumstances, lead to noises in the domestic water heat exchanger of the hot water storage tank.




- a Drinking water heat exchanger (EKHWDH500B, EKHWD500B, EKHWC500B, EKHWC500PB, EKHWC500PB, EKHWC500PB)
- b Drinking water heat exchanger (EKHWC300B, EKHWC300PB)
- c Storage tank charging heat exchanger 1 or 2 (EKHWDH500B, EKHWD500B, EKHWC500B, EKHWC500PB, EKHWC500B, EKHWC500PB)
- d Storage tank charging heat exchanger 1 (EKHWC300B, EKHWC300PB)
- e Heating support heat exchanger (EKHWC500B, EKHWC500PB, EKHWC500B, EKHWC500PB)

Δp /mbar Pressure drop in millibar
m / L/h Flow rate in litres per hour
m / L/h Flow rate in litres per minute

Fig. 9-2 Pressure drop characteristic for the heat exchanger

9.2.2 EKHP



S#B EKHP500B
S#D EKHP300B
S#F EKHP500PB
S#G EKHP300PB


Z / L/min
Draw-off rate in litres per minute
 $V_{z,max}$ / L
Maximum draw-off rate in litres

Hot water volume without re-heating ($T_{KW} = 10^\circ\text{C}$, $T_{WW} = 40^\circ\text{C}$, $T_{SP} = 60^\circ\text{C}$).

Fig. 9-3 Hot water output with respect to draw-off rate



Draw-off rates >36 l/min can, in certain rare circumstances, lead to noises in the domestic water heat exchanger of the hot water storage tank.



- a Drinking water heat exchanger (EKHP500B, EKHP500PB)
- b Drinking water heat exchanger (EKHP300B, EKHP300PB)
- c Storage tank charging heat exchanger 1 (EKHP500B, EKHP500PB)
- d Storage tank charging heat exchanger 1 (EKHP300B, EKHP300PB)
- f Heating support heat exchanger (EKHP500B, EKHP500PB)

Δp /mbar Pressure drop in millibar
m / L/h Flow rate in litres per hour
m / L/h Flow rate in litres per minute

Fig. 9-4 Pressure drop characteristic for the heat exchanger

9 Technical data

9.3 Tightening torque

Name	Thread size	Tightening torque
Hydraulic line connections (Water)	1"	25 to 30 Nm
Electric immersion heater / booster heater	1.5"	max. 10 Nm (hand-tight)
Cabling on terminal rail K1 (EHS)	all	0.5 - 1.5 Nm
Tension release (EHS)	M20	6 Nm
Cover flap fixing screws (EHS)	4.2 x 19	1.5 Nm

Tab. 9-6 Tightening torque

10 Notes

[illegible]

10 Notes

[illegible]

11 List of keywords

Numerics

3-way switch valve 24

A

Additional water 6

B

Booster heater 25

C

Check list for start-up 20

Cleaning 25

Convection brake 8, 14

Corrosion protection 6

D

Danger of frost 21

Design and components 8

Dirt filter 14, 16

Disposal 22

Distance from ceiling 16

Domestic water pipes 16

Draw-off volume 31

E

Electric immersion heater 14, 20

Electrical installation 6

Electronic control 13

E-PAC 6, 15, 17, 29

Explanation of symbols 5

F

Filling 18

Filling water 6

H

Housing installation room 6

I

Installation 15

K

KFE filling connection 14, 21

M

Minimum distance 16

N

Name plate 8

O

Operating mode 13

Operating safety 6

P

Performance diagrams 31

Periodic Checks 25

R

Relevant documents 4

S

Sacrificial anode 13, 25

Safety overflow connection 17

Sanitary connection 7

Scalding protection 14, 16

Scope of delivery 13

Service 25

Shutdown 21

Solar storage tank extension kit

Overview 14

Start-up

Checklist 20

Storage tank connection kit 6, 15, 17

T

Taking out of operation

Final 22

Temporary 21

Tapping rate 31

Technical data

Basic storage tank data 26

Tightening torque 32

U

Use as intended 6

W

Warnings 5

Water hardness 20

Water pressure 17

DAIKIN EUROPE N.V.

Zandvoordestraat 300, B-8400 Oostende, Belgium

008.1618744_05

Copyright © Daikin

03/2017